



Polycom Manual Configuration

Mike Johnstone - 2025-04-13 - Polycom Devices

Polycom Manual Configuration

Manual configuration

You can quickly configure a handset by supplying four simple pieces of information in 2.1 with all other steps being optional.

1. Retrieve the handset IP address: Home (Button) > Settings > 4. Status > 2. Network > 1. TPC/IP.
2. Web UI: Enter IP address (eg 192.168.1.11) into your browser.
3. Settings > Lines (select Line).

Follow instructions from the image below

1. SIP Protocol: Enable.
2. Identification: Display Name, Address (must be full DID), Label (usually same as Display Name).
3. Authentication: User ID (full DID), Phone's password from your switchboard, Disable Credentials.
4. SIP Server 1: plus.2talk.com - Expires 180

Line 1

SIP Settings

SIP Protocol Enable Disable

H.323 Settings

Identification

Display Name **1**

Address

Label

Type Private Shared

Third Party Name

Number of Line Keys

Calls Per Line

Enable SRTP Yes No

Offer SRTP Yes No

Require SRTP Yes No

Server Auto Discovery Enable Disable

Authentication

Use Login Credentials Enable Disable **2**

Domain

User ID

Password

Outbound Proxy

SIP Server 1

Special Interop **3**

Address

Port

Transport

Expires (s)

Subscription Expires (s)

Register Yes No

Retry Timeout (ms)

Retry Maximum Count

Line Seize Timeout (s)

Tags

Device

Polycom