



[Knowledge Base](#) > [Handsets and Device Provisioning](#) > [Polycom Devices](#) > [Polycom Manual Configuration](#)

## Polycom Manual Configuration

Mike Johnstone - 2025-09-13 - [Polycom Devices](#)

## Polycom Manual Configuration

### Manual configuration

You can quickly configure a handset by supplying four simple pieces of information in 2.1 with all other steps being optional.

1. Retrieve the handset IP address: Home (Button) > Settings > 4. Status > 2. Network > 1. TPC/IP.
2. Web UI: Enter IP address (eg 192.168.1.11) into your browser.
3. Settings > Lines (select Line).

Follow instructions from the image below

1. SIP Protocol: Enable.
2. Identification: Display Name, Address (must be full DID), Label (usually same as Display Name).
3. Authentication: User ID (full DID), Phone's password from your switchboard, Disable Credentials.
4. SIP Server 1: plus.2talk.com - Expires 180

**Line 1**

**SIP Settings**

SIP Protocol ☒ Enable ☐ Disable

**H.323 Settings**

**Identification**

Display Name  1

Address

Label

Type ☒ Private ☐ Shared

Third Party Name

Number of Line Keys

Calls Per Line

Enable SRTP ☒ Yes ☐ No

Offer SRTP ☐ Yes ☒ No

Require SRTP ☐ Yes ☒ No

Server Auto Discovery ☒ Enable ☐ Disable

**Authentication**

Use Login Credentials ☐ Enable ☒ Disable 2

Domain

User ID

Password

**Outbound Proxy**

**SIP Server 1**

Special Interop  3

Address

Port

Transport

Expires (s)

Subscription Expires (s)

Register ☒ Yes ☐ No

Retry Timeout (ms)

Retry Maximum Count

Line Seize Timeout (s)

- Tags
- [Device](#)
- [Polycom](#)