



## Device Provisioning - Grandstream ATA

Mike Johnstone - 2025-01-31 - Device Provisioning

# Device Provisioning - Grandstream ATA

Registering your **Grandstream** in our **Device Provisioning** ensures that you can get your Grandstream up and running in minutes.

1. Log into your [account](#).
2. Click on **Tools | Device Provisioning**.
3. Choose **Add Device**.
4. Select **Device Type** (Grandstream type).
5. **Line Settings | Select Phone Number | Grandstream | Name Device**
6. Supply **MAC address**.
7. Add **Time zone | Time Format**
8. Line Key2: Select **Number or Feature**
9. If this is a BYO Yealink Select '**SAVE**' and manually restart the handset.
10. Once provisioned by our Device Provisioning any further changes made from within the portal will automatically restart the handset to reflect your changes

## Add device

↑ Yealink Bulk upload

|                 |                  |                   |                   |
|-----------------|------------------|-------------------|-------------------|
| Line settings   | 19525250273      | Grandstream HT81X | Bosley Mannetonka |
| Line settings   | 19525250274      | Grandstream HT81X | 0274              |
| Line settings   | 19525250275      | Grandstream HT81X | 0275              |
| Device settings | c074ad9d15ec     | 207GjSNN519D15EC  |                   |
| Time settings   | America/New_Y... | 12                |                   |

Tags

Device

Provisioning