

Knowledge Base > Handsets and Device Provisioning > Device Provisioning > Device Provisioning - Grandstream ATA

Device Provisioning - Grandstream ATA

Mike Johnstone - 2025-12-06 - Device Provisioning

Device Provisioning - Grandstream ATA

Registering your **Grandstream** in our **Device Provisioning** ensures that you can get your Grandstream up and running in minutes.

- 1. Log into your account.
- 2. Click on **Tools** | **Device Provisioning**.
- 3. Choose Add Device.
- 4. Select **Device Type** (Grandstream type).
- Line Settings | Select Phone Number | Grandstream | Name Device
- 6. Supply **MAC address**.
- 7. Add **Time zone** | **Time Format**
- 8. Line Key2: Select **Number or Feature**
- 9. If this is a BYO Yealink Select '**SAVE**' and manually restart the handset.
- 10. Once provisioned by our Device Provisioning any further changes made from within the portal will automatically restart the handset to reflect your changes

Add device Line settings Grandstream HT81X ~ Bosley Mannetonka 19525250273 Line settings 19525250274 Grandstream HT81X 0274 Line settings 0275 19525250275 Grandstream HT81X Device settings c074ad9d15ec 207GJSNN519D15EC Time settings America/New_Y... 12

- Tags
- <u>Device</u>
- <u>Provisioning</u>