



[Knowledge Base](#) > [Handsets and Device Provisioning](#) > [Device Provisioning](#) > [Device Provisioning - Grandstream ATA](#)

Device Provisioning - Grandstream ATA

Mike Johnstone - 2025-12-26 - [Device Provisioning](#)

Device Provisioning - Grandstream ATA

Registering your **Grandstream** in our **Device Provisioning** ensures that you can get your Grandstream up and running in minutes.

1. Log into your [account](#).
2. Click on **Tools | Device Provisioning**.
3. Choose **Add Device**.
4. Select **Device Type** (Grandstream type).
5. **Line Settings | Select Phone Number | Grandstream | Name Device**
6. Supply **MAC address**.
7. Add **Time zone | Time Format**
8. Line Key2: Select **Number or Feature**
9. If this is a BYO Yealink Select '**SAVE**' and manually restart the handset.
10. Once provisioned by our Device Provisioning any further changes made from within the portal will automatically restart the handset to reflect your changes

Add device

⬆ Yealink Bulk upload

Line settings	19525250273 ▾	Grandstream HT81X ▾	Ilosley Mannetonka
Line settings	19525250274 ▾	Grandstream HT81X	0274
Line settings	19525250275 ▾	Grandstream HT81X	0275
Device settings	c074ad9d15ec	207GJSNN519D15EC	
Time settings	America/New_Y... ▾	12 ▾	

- [Tags](#)
- [Device](#)
- [Provisioning](#)