



Device Provisioning - Grandstream ATA

Mike Johnstone - 2025-07-30 - Device Provisioning

Device Provisioning - Grandstream ATA

Registering your **Grandstream** in our **Device Provisioning** ensures that you can get your Grandstream up and running in minutes.

1. Log into your [account](#).
2. Click on **Tools | Device Provisioning**.
3. Choose **Add Device**.
4. Select **Device Type** (Grandstream type).
5. **Line Settings | Select Phone Number | Grandstream | Name Device**
6. Supply **MAC address**.
7. Add **Time zone | Time Format**
8. Line Key2: Select **Number or Feature**
9. If this is a BYO Yealink Select '**SAVE**' and manually restart the handset.
10. Once provisioned by our Device Provisioning any further changes made from within the portal will automatically restart the handset to reflect your changes

Add device

↑ Yealink Bulk upload

Line settings	<input type="text" value="19525250273"/> ▾	<input type="text" value="Grandstream HT81X"/> ▾	<input type="text" value="Bosley Mannetonka"/>
Line settings	<input type="text" value="19525250274"/> ▾	<input type="text" value="Grandstream HT81X"/>	<input type="text" value="0274"/>
Line settings	<input type="text" value="19525250275"/> ▾	<input type="text" value="Grandstream HT81X"/>	<input type="text" value="0275"/>
Device settings	<input type="text" value="c074ad9d15ec"/>	<input type="text" value="207GjSNN519D15EC"/>	
Time settings	<input type="text" value="America/New_Y..."/> ▾	<input type="text" value="12"/> ▾	

Tags

Device

Provisioning