



[Knowledge Base](#) > [Handsets and Device Provisioning](#) > [Grandstream - Manual setup](#)

Grandstream - Manual setup

Mike Johnstone - 2024-10-27 - [Handsets and Device Provisioning](#)

Grandstream - Configuring your phone

Quick Guide to Grandstream

In addition to the Grandstream ATA 80x we now support Grandstreams latest GRP handsets via our device provisioning.

- Retrieve the phones IP address > select the Settings button (highlighted below)
- Status | Network Status | Ethernet | IPV4 address
- Advanced settings: in browser type `http://<address>` to access web admin mode.



Select Settings

Status
Network Status
Ethernet
IPV4 Address

1. General Setting

- Activate Account: Enable
- Account Name: Can phone and owner name (eg Sally)
- SIP user ID: Phone number
- SIP Auth ID: Phone number
- SIP server: call.sipcity.com.au

2. SIP setting (tab)

- SIP Registration: Enable
- Subscribe Exp: 60
- SIP Transport: TLS
- Local SIP port: 5061

Accounts

Account 1

Account 2

Account 3

Account 4

Account 5

Account 6

General Settings

SIP Settings

Codec Settings

Call Settings

Advanced Settings

Dial Plan

Hidden Number Plan

Feature Codes

Account Register

Account Active ?



Account Name ?

19497993303

SIP Server ?

call.sipcity.com.au

Secondary SIP Server ?

Outbound Proxy ?

Secondary Outbound Proxy ?

SIP User ID ?

19497993303

SIP Authentication ID ?

19497993303

SIP Authentication Password ?

.....

Name ?

GD 3303

Tel URI ?

Disabled

Voicemail Access Number ?

BLF Server ?

Account Display ?

Username

UCM User Password ?