

Knowledge Base > Handsets and Device Provisioning > Yealink Devices > Yealink T48G Bluetooth Headset

Yealink T48G Bluetooth Headset

Mike Johnstone - 2025-10-26 - Yealink Devices

Yealink T48G Bluetooth Headset

The T48G can be purchased with an optional USB Bluetooth Dongle used to connect the Bluetooth headset.

- 1. Insert the USB dongle with "TOP" facing upwards into the USB port of the back of the phone.
- 2. Turn on the Bluetooth headset.
- 3. Long press the pairing button on your Bluetooth headset.
- 4. Activate the Bluetooth feature on the phone.
- 5. Select Scan on the phone.
- 6. If required enter the PIN 0000 or 1234 to connect the phone and headset.
- Tags
- <u>Device</u>
- Yealink