



## Manually Provision a Yealink phone

Mike Johnstone - 2025-03-14 - Yealink Devices


# Manually Provision a Yealink phone

Access Yealink Phone's Web UI

1. Phone's web UI: to access the phone's web UI press the **OK** button (on the right of the keypad) to retrieve the phone's IP address.
2. Enter the **IP address** on your browser (eg 192.168.1.xx).
3. **Username** and **Password**: admin/admin.
4. Click **Confirm**.

Account Tab

1. Select the Account tab. (or another unused account if Account 1 is in use).
2. Account Active: **Enable**
3. Label: **Your Name**
4. Display Name: Displays on your telephone phone screen when idle.
5. Register Name: **Full DID** eg 13106341780
6. User Name: **Full DID** eg 13106341780
7. Password: **account password** or the restricted line password – can be found on your account's switchboard.
8. SIP Server: **plus.2talk.com**
9. Port: **5061**
10. Transport: **TLS**
11. Confirm: to **Save**

|                     |                                                                                              |           |
|---------------------|----------------------------------------------------------------------------------------------|-----------|
| <b>Account</b>      | Account1                                                                                     | ▼         |
| Register Status     | Registered                                                                                   |           |
| Line Active         | Enabled                                                                                      | ▼         |
| Label               | Ext 1780                                                                                     |           |
| Display Name        | 13106341780                                                                                  |           |
| Register Name       | 13106341780                                                                                  |           |
| User Name           | MikeJ                                                                                        |           |
| Password            | ••••••••  |           |
| <b>SIP Server 1</b> |                                                                                              |           |
| Server Host         | plus.2talk.com                                                                               | Port 5061 |
| Transport           | TLS                                                                                          | ▼         |
| Server Expires      | 120                                                                                          |           |
| Server Retry Counts | 3                                                                                            |           |

Etiquetas  
Device  
Yealink